

## QUICK GUIDE TO ACCESSIBILITY FEATURES (for use with TiVo DVR or Mini)

### SCREEN READER

- Using the TiVo remote, press and hold the yellow “A” button (located above the numbered buttons) for two seconds to turn Screen Reader on or off. A voice will say “screen reader on” when activated.
- Use the same instructions above to turn screen reader off. A voice will say “screen reader off” when deactivated.

### CLOSED CAPTIONING

- To turn Closed Captioning on, press the TiVo Home button which is located at the top of the remote.
- Using the left arrow key, select ‘Menu’ from the options bar, and push ‘ok’ on your remote.
- Using the right arrow key select ‘Settings’ from the options bar, and then use the down arrow key to highlight ‘Accessibility’ and push ‘ok’ on your remote.
- ‘Closed Captioning’ will already be highlighted from the list choices and push ‘ok’ on your remote.
- Using the up/down arrow keys, you can change closed captioning on/off and then push ‘ok’ on your remote.
- If you prefer to alter font size, text color, etc for closed captioning, go back to Accessibility menu and choose ‘Closed Captioning Preferences’.
- Press the ‘Live TV’ button to go back to watching TV.

### AUDIO DESCRIPTION

- To turn Audio Description on, press the TiVo Home button which is located at the top of the remote.
- Using the left arrow key, select ‘Menu’ from the options bar, and push ‘ok’ on your remote.
- Using the right arrow key select ‘Settings’ from the options bar, and then use the down arrow key to highlight ‘Accessibility’ and push ‘ok’ on your remote.
- Using the down arrow key, select ‘Language & Audio Description’ from the list choices and push ‘ok’ on your remote.
- Choose from the list of choices and push ‘ok’ on your remote.
- Press the ‘Live TV’ button to go back to watching TV.